


## Insertion of tubes



1. open pivoted lever



4. pull tube tight and insert the tube cartridge



2. remove tube cartridge



5. close pivoted lever until it locks



3. insert appropriate tube

At the first time of usage please control the pressure of tubing and if necessary adjust it (see manual )

Commercial tubes without stopper can be used !